

Molten Salt Oxidation Technical Overview

Kevin B. Ramsey
Power Source Technology (NMT- 9)
Los Alamos National Laboratory

December 9, 1999
Southwest Technology Deployment Workshop

Program Objectives

- Stabilize ^{238}Pu -contaminated combustible waste
- WIPP waste acceptance criteria compliance
- Recover ^{238}Pu
- Technology deployment
- Waste volume reduction

Benefits

- Removes combustible component of ^{238}Pu -contaminated wastes
- Recovery of ^{238}Pu for reuse in heat source operations
- Significant reduction of the volume of TRU waste requiring disposal
- Legacy and newly generated waste disposal cost savings

^{238}Pu -Contaminated Materials

- Polypropylene (PP) bottles
- High density polyethylene (HDPE) bottles
- Gloves
- Bagout bags (PVC)
- Tygon™ tubing
- Cheesecloth wipes (cotton)
- Pyrolysis ash
- Non-RCRA organics

Combustible Materials



Molten Salt Oxidation (MSO)

- Hydrocarbons react with oxygen to form H_2O and CO_2
- Molten salt (e.g., Na_2CO_3) serves as a catalyst for the oxidation reaction
- Temperature of reaction: 900°C
- No open flame
- Acidic species such as F, Cl, Br, I, S, and P react with Na_2CO_3 to form neutralized salts
- Metal species are retained in the molten salt as metal oxides or salts

MSO Process Design

- Mature waste treatment technology
- Rapid implementation
- Solid and liquid materials can be treated
- Inorganics retained in ash
- Low pressure
- TransOxTM system compatible with glovebox operation
- Semi-batch process


MSO Process Design - continued

- Safe operation and minimal handling of ^{238}Pu -contaminated materials
- Throughput of 2 kg/hr
- Minimal feed pretreatment
- Minimal treatment of offgas and waste
- Reduction of TRU waste volumes
- Salt recycling with ^{238}Pu recovery by aqueous processing


MSO Process Limitations

- Maximum concentration of ash: 20 wt. %
- Maximum concentration of neutralized salt: 95 wt. %
- Removal of spent salt is required to maintain continuous operation
- Limited to treatment of combustible wastes
- Corrosion
- Size


Traditional MSO Reactor



Molten Salt Oxidation Process



MSO Process Line



Pretreatment

- Size reduction required for solids
 - 0.95 cm (0.375 inch) material size
 - Granulation technology (Rapid Granulator, Inc.)

Size Reduction



Size Reduction



LA-UR-99-6387

Los Alamos
Nuclear Materials Technology


TransOx™ System

- Aluminized Inconel 600 construction
- Internal heating/external cooling
 - Better temperature control
 - Increased energy efficiency
 - Increased throughput
- “Skull” layer of salt
- Salt drain system
- Automated operation


TransOx™ System

- Minimal salt/metal contact
- Extended vessel life
- Decreased maintenance
- Continuous operation not required

TransOx™ System



Salt Recycling Process



Surrogate Materials Results

| Material | % Cl | Destruction Efficiency |
|--|------|------------------------|
| Polypropylene (PP) | 0 | 99.998 |
| High Density Polyethylene (HDPE) | 0 | 99.983 |
| Gloves | 0 | 99.997 |
| Tygon Tubing | 30 | 99.999 |
| Pyrolysis Ash (9% wt. in ethylene glycol) | 0 | 99.987 |
| Ethylene Glycol | 0 | 99.999 |
| Bagout Bags | 36 | 99.988 |
| Homogenized Mixture | 20.5 | 99.974 |
| Average | | 99.991 |

NSWC-IH

Milestones

- Complete equipment and glovebox design (09-30-99)
- Complete procurement of major equipment and gloveboxes (01-30-00)
- Complete installation of equipment and gloveboxes (09-30-00)
- Begin processing legacy waste (09-30-00)

Deployment Opportunities

- Los Alamos National Laboratory
 - Chemistry and Metallurgy Research Facility
- Savannah River Site
- Rocky Flats Environmental Technology Site

Legacy Waste

- 7500kg of ^{238}Pu -contaminated combustible waste in storage at TA-54 and TA-55
- No treatment/packaged to meet WIPP requirements
 - 8700 drums/1831 m³
- MSO treatment/no ^{238}Pu recovery/WIPP disposal
 - 420 drums/88 m³
- MSO treatment/aqueous recovery of ^{238}Pu /WIPP disposal (50% process efficiency for aqueous recovery)
 - 190 drums/ 40 m³

MSO Web Site

<http://www-emtd.lanl.gov/ASTD-NM/MSO.html>